



Thank you for purchasing a Hip Street product and we hope you enjoy using it. Please visit our website at www.hipstreetonline.com.

Preface

Kindly read and retain all the operating instructions before operating the unit. We cannot assume any liability that may arise out of improper operation or incidental/accidental damages. The contents of this user manual are subject to change based on newer developments.

Introduction


The Hip Street Bluetooth headset allows you the freedom to make and receive calls while on the move or in the office. You can connect the headset to a compatible phone that supports Bluetooth wireless technology.

Bluetooth wireless technology

Bluetooth wireless technology makes it possible to connect compatible communication devices without using cables. A Bluetooth connection does not require that the phone and the headset be in line of sight, but both devices should be within 10 meters of each other.

Overview

The figure below shows the main parts of the headset:



1. Answer/End (Talk) key
2. Indicator light (Power/Pairing Mode)
3. Volume keys
4. Microphone
5. Earphone
6. Charging connector

Before you can start using the headset, you must fully charge the battery.

Charging the battery

This device has an internal, non-removable, rechargeable battery. Do not attempt to remove the battery from the device as you may damage the device and void the warranty.

1. Connect the charging cable to the headset.
2. Connect the other end of the charging cable to an available USB port on your computer or laptop. (The computer or laptop must be powered on to charge the headset.) The red indicator light on the headset is displayed during charging. If the charging light does not come on, disconnect the charging cable and retry. Full charge may take up to 1.5 hours.
3. When the battery is fully charged, the red indicator light on the headset will turn off.
4. Disconnect the charging cable from the headset and computer or laptop.

The fully charged battery will power the headset for up to 6 hours of talk time or up to 200 hours of standby time. Please note these values may vary depending on the various usage scenarios and with different mobile phones. When the battery is running low on power, the red indicator light will start to flash.

Turn the headset ON / OFF

1. To switch the headset on, press and hold the Answer/End key for 3 seconds. The blue indicator light will start to blink.
2. To switch the headset off, press and hold the Answer/End key for 3 seconds until the headset beeps 2 times and the red indicator light displays briefly.

Pairing the headset

1. Make sure your headset is turned OFF with no lights blinking.
2. Press the Answer (Talk) key for 7 seconds or until the blue and red lights blink alternately.
3. Activate the Bluetooth feature on the mobile phone or Bluetooth compatible device and set it to search for devices (See the user guide of your mobile phone or device for instructions).
4. Select the headset "HIP STREET" from the list of found devices.
5. Enter the pass code "0000" to pair the headset to your phone or Bluetooth compatible device.
6. If the pairing is successful, the headset's blue light will flash 3

times briefly for the first time, followed by a single flash every 7 seconds.

7. Repeat steps 1 through 6 if pairing is not successful.

Troubleshooting

If you cannot connect the headset to your phone, do as follows:

1. Ensure the headset is charged then go through the steps listed to pair your headset.
2. Ensure that the Bluetooth feature is activated on your phone.
3. Check to ensure the headset is within 10 meters of your mobile phone or Bluetooth device and that there are no obstructions that may prevent connectivity.

Call Handling

1. To make a call, use your mobile phone in the normal way when the headset is connected to your phone. The audio will be directed to the headset.
2. If your mobile phone supports redialing via Bluetooth headsets, press the volume + key for 2 seconds to redial the last number called.
3. If your mobile phone supports voice dialing via Bluetooth headsets, press the Answer/End key and proceed as described in the user guide of your mobile phone.
4. To answer a call, press the Answer/End key, or use the mobile phone call answer button. If the automatic answer function is available on your mobile phone and enabled, incoming calls will automatically be answered after one ring.
5. To end a call, press the Answer/End key while in a call, or use the call end button on your mobile phone.

Adjusting the earphone volume

1. Press the volume key up to increase or down to decrease the volume during a call.

Battery information

1. Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
2. Do not leave a fully charged battery connected to the computer or laptop, as overcharging may shorten the rechargeable battery lifetime.
3. Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Care and maintenance

Your headset is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage. Keep all accessories and enhancements out of the reach of small children.

1. Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, wipe it dry immediately and allow it to dry completely.
2. Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
3. Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
4. Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
5. Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
6. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
7. Do not paint the device. Paint can clog the moving parts and prevent proper operation.

Need assistance? Please call us!

If you encounter any difficulties with this product, please visit our website at www.hipstreetonline.com and review our support section or call us. Our representatives are ready to help you with any questions about your product. We can guide you through connections, first-time use, or any of the features. Just give us a call or send us an email.

Customer & Technical Support: **1-888-4KOBIAN** or **1-888-456-2426**
Monday through Friday: 8:30am – 5:00pm EST
Email: support@hipstreetonline.com

We want you to start enjoying your product right away!